



(ON OFF)

()

RS -232/USB/SNMP

« » , . ,17; ∴ (+375-17) 291-15-05;
www.unibelus.com

	5 ()							
	10 ()							
	: 5 ,				: 8			
	80 ()							
	110%				60			
	120%				5			
	20 ()							
AC	4 ,				40			
	0,2							
	1							
	24	24	36	48	24	36	48	48
	2 12 7	2 12 8	3 12 8	4 12 8				
	1,2 (.)				12 (.)			
	90% 8							
	RS232/USB/SNMP ()							
IP	IP20							
	0 ~ 40 °							
	10 ~ 90 % ()							
	50 (1)							
(),	145 360 215		145 360 215	200 475 337	145 360 215			200 475 337
(),	236 427 316		240 510 320	320 592 462	325 450 245			320 592 462
(),	14,5	15,5	18,5	27	8,9	10,4	13,2	22,5
(),	15,5	16,5	19,5	28,6	9,6	11,2	13,9	23,2



- ❶ Обходной режим ❷ Батарея (зеленый - AC режим
красный - режим инвертора)
- ❸ Вход перем. тока ❹ LCD
- ❺ Выход перем. тока

1 –



2 –