

# UNEX

системы видеонаблюдения

РУКОВОДСТВО ПОЛЬЗОВАТЕЛЯ

/

«


»

UXTP-01B



« »

/



- PAL, NTSC, SECAM
- BNC(m)
- 
- 
- 
- 

5 6

300


800

:

:		
	0-6	
	1.5	
/	15 -5 60	
	75	
<b>UTP</b>	100	
:		
	24 AWG	3
	18 /100	
	62 /	
.	Cat 3 – 150 ; Cat 5 – 225	
.	Cat 3 – 380 ; Cat 5 – 550	
:		
	: -25° 70 °	
	0~95%	



	6000 ; 1.2 $\mu$ x50 $\mu$
	25
	14 ; 16 ; 51



--- BNC(m)

--- - (UTP )


--- +(UTP )

300 (1000 )



UXTP -01B


UXTP -01B



UXTP -01B


UXTP S-P16

800 (2667 )



UXTP -01A

UXTP-V-AR



UXTP -01A

UXTP S-A16